MAINTENANCE OF FACADES

ONEWOOD MAINTENANCE MANUAL

No	Problem	Maintenance and solution
1.	Dust and dirt	The surface must be regularly cleaned with water to remove dust and dirt. For removing heavier dirt, use a pressure washer, and soapy water if necessary.
2.	Plants and leaves	To remove heavier dirt, use a pressure washer, and soapy water or a weak aqueous solution of oxalic acid if necessary.
3.	Rust	Remove loose dirt with a brush and rinse with water; use detergent and warm water to remove stains. In case of heavier dirt, use an aqueous solution with a low content of oxalic or phosphoric acid and rinse with water.
4.	Cement	Remove chunks of cement with a brush and wash with a pressure washer. Use detergent and warm water to remove stains. In case of severe damage, let the surface dry thoroughly and use low-grit sandpaper to remove the cement.
5.	Paint and oil stains	Soapy water, or a detergent containing acetone or methanol, is suitable for cleaning. In case of heavier dirt, let the surface dry thoroughly, use low-grit sandpaper to remove stains, and use the cleaning agent again if necessary.
6.	Mold	To prevent mold, the surface must be regularly cleaned and washed. To remove mold, use a pressure washer and scrub with a brush. In case of severe mold, use soapy water or special anti-mold cleaning agents available in stores.
7.	Scratches	Lighter scratches will disappear over time; use low-grit sandpaper to remove deeper damage marks.



NB!

1. Use neutral pH solutions and detergents for cleaning surfaces. Stronger detergents may bleach and permanently affect the color of the surface.
2. Industrial chemicals must never be used for cleaning surfaces, as they can permanently bleach and damage the surface.
3. Use only a soft-bristled brush to clean surfaces to avoid scratching the surface.
4. Use detergents containing oxalic acid and methanol in low concentrations. If necessary, increase the concentration gradually by adding it to water.
5 .It is recommended to use sandpaper with a grit of 40–100. Do not use a sanding machine!
6. It is not recommended to sand surfaces with a wood grain pattern. Sanding will permanently remove the textured surface.
7. When using a pressure washer, the nozzle must not be closer than 300 mm to the facade surface.



Arendatud põhjamaise kliima jaoks.
Developed for nordic climate.

© All materials presented are the property of OneWood OÜ.
Any use without their permission is prohibited.